





8. Leiterplatte, komplett – SKR 550
 Leiterzugseite
 Einlage IV
 Änderungen vorbehalten!





LED X2802
Suchlauf
search system


NF NF' LG
X1211 X3513
TA radio
aux



EBC
SC 236
E C B
SD 335
KAA
SAM42
SZX 21

LW X0701

A/W - Kopf
r/p - head



6.5. Stromlaufplan-Kassettenelektronik-SKR 550
Einlage III
2329.00-01.00 (Sp)
Änderungen vorbehalten!

Bandsortenschalter

3°	5°	S1511
4°	6°	
3°	5°	S1512
4°	6°	
3°	5°	S1561
4°	6°	

1281 1282
1381 1382

2205 2208
2206 2209
2305 2308
2306 2309
2207
2307

2210
2310

2211
2311

2213
2215
2216
2218

1284
1384

1281
1381

2203 2201
2303 2301


2204
2304

2205
2305

2208
2308

2210
2310

2201




Ansicht von unten
bottom views

von oben

EBC
SC 236
SC 308

KAA
SAM 42


A K
VQA 18, 28, 38



ECB
SD 335

KKA
SAL 41


A K
SAY 20
SZ X 19




SF 826

K A
VQA 23



A K
SZ 600







6.4. Stromlaufplan-LED-SKR 550
 Einlage II
 2329.00-01.00 (Sp)
 Änderungen vorbehalten!


R		7701 7702 8701 8702	1201 1301 1202	1303 1302 1304	1203 1204	1205 1305	1206 1306 1207 1307	1210 1211 1310 1311	1213 1313	1314 1214	1260 1261	1262	1215 1315	1216 1316 1317	1220 1221 1320 1321	1263 1218 1318	1222 1223 1322 1323	1226 1207
C			1325		1225	1201 1301	1202 1302	1240 1241			1242		1204 1304	1243 1205 1305			1206 1307 1306	1207 1210 1310
L																		



von unten / Vorderansicht
front / bottom views



SAY 20; SY 351



BAS	≙	MODE	IBETRIEBSART
SFS	≙	FUNCTION	FUNKTION
UST	≙	AL TIME	ALARM ZEIT
SAT	≙	SELECT	ANWAHL
ASW	≙	AL OFF	ALARM AUS
EKT	≙	SET	SETZEN
RPT	≙	REPEAT	ALARM WIEDERHLS.
RZ 2	≙	SLEEP	EINSCHLAFEN

Modul Kal 41-22-01-01

2329.00-01.00 (Sp)
Änderungen vorbehalten!